














Please unscrew all hardware from cushion before assembly.




FURNITURE

www.elizatinsleyfurniture.co.uk

MODEL : BCL/C335

(1)x1  Back Cushion	(2)x1  Seat Cushion	(3)x1 (L)x1 (R)  Left & Right-Arm
(4)x1  Gas Lift W/ Cover	(5)x1  Base	(6)x1  Mechanism
(7)x5  Caster		
(A)*4 	M8*22 Mechanism Screws	
(B)*4 	M8*36 Arm Screws	
(C)*4 	M6*30 Back Bar Screws	
(D)*4 	ARM CAPS	
(E)*2 	ALLEN KEY	



Note: Please tighten all arm screws using allen key before step 6

It is important to assemble all parts so that the directional "Arrows" point in the same direction. Make certain that all screws are FULLY tightened before using the chair. Each month, check all screws and tighten any that may have loosened

